

## Milk system cleaner

### Liquid cleaner for milk systems for JURA fully automatic coffee machines

#### Mode of action

Alkaline cleaning liquid especially developed for Jura fully automatic coffee machines for thorough removal of milk deposits and milk fat. The formulation is tailored to use in Jura fully automatic coffee machines and ensures effective while gentle cleaning, thereby extending the life of your coffee machine. The liquid cleaner can also be used for other devices such as milk frothers.

#### Properties

Liquid, transparent yellowish  
Characteristic odour  
Soluble in water.  
pH (20°C), 12° dH:  
10 ml/100 ml: 11,0-11,5

#### Ingredients

(according to regulation (EC) No  
648/2004)

AQUA

SODIUM CARBONATE

SODIUM 3-[(2-CARBOXYETHYL)(2-  
ETHYLHEXYL) AMINO]PROPANOATE

SODIUM POLYACRYLATE

POTASSIUM HYDROXIDE

For more information on the ingredients  
please click [here](#).

#### Instructions for use

1. Use Milk system cleaner according the instructions for use of your machine. Take care to use the correct quantity of cleaner and the correct quantity of fresh water.
2. Start the cleaning operation as described in the instructions for use of your machine.
3. After cleaning, rinse the device with fresh water according to the instructions for use of your machine.

#### Toxicological and ecological information

The product is classified as irritant, i. e., short, frequently or prolonged contact with skin or mucous membrane may cause inflammations.

The operation of public sewage treatments plants is not affected even if added in larger amounts. The product complies with the biodegradability criteria as laid down in Regulation (EC) No.648/2004 on detergents.

#### Handling, storage and disposal considerations

Put lid on container after use. Keep in the original container or a storage container. Keep container tightly closed. Store in a cool, dry place.

Waste code product: 20 01 29

Residues of the product can be disposed of in the normal drainage system.

#### Hazards identification

Warning

H315: Causes skin irritation.

H319: Causes serious eye irritation.

P102: Keep out of reach of children.

P264: Wash hands thoroughly after handling.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P332+P313: If skin irritation occurs: Get medical advice/attention.

P337+P313: If eye irritation persists: Get medical advice/attention.

#### First aid measures

In case of accident or if you feel unwell, seek medical advice immediately (show directions for use or safety data sheet if possible). Change **contaminated, saturated clothing** immediately.

If the liquid or the solution get into contact with the **eyes**, flush immediately with plenty of flowing water for 10 to 15 minutes holding eyelids apart and consult an ophthalmologist.

If the liquid or the solution is **swallowed**, rinse the mouth immediately and drink plenty of water. Do not induce vomiting. Seek medical advice if you feel unwell.

If the liquid or the solution gets into contact with the **skin**, wash immediately with plenty of water.

#### Packing units

Bottle of 100 ml

Bottle of 250 ml

Bottle of 1.000 ml

#### Art. No.

66549, 63801, 70700, 62536,  
65917, 71320

**JURA Elektroapparate AG**  
**Kaffeeweltstraße 10**  
**CH-4626 Niederbuchsiten**  
**Tel.: +41 (0) 62 389 81 81**  
**www.jura.com**

**JURA Gastro Vertriebs-GmbH**  
**An der Zugspitze 1**  
**D-82491 Grainau**  
**Tel.: +49 (0) 8821 966 73-0**  
**www.juragastroworld.de**